
INSTRUCTIONS

How to install:

202A Headrest P/N 92328

3PT Grab Handle P/N 14520 (Black) 14524 (Yellow)

US Armrest P/N 54130339 (Right) 54130341 (Left)



Video Instructions:

<https://www.freedmanseating.com/video/install-202a-headrest-3pt-grab-us-armrest/>

Questions? Contact the Parts Department.

Email: partsdept@freedmanseating.com

Phone: (773) 524-2440 Ext. 413

202A Headrest P/N 92328 3PT Grab Handle P/N 14520 (Black) 14524 (Yellow)

The 202A Headrest and 3PT Grab Handle require the same instructions for installing/adding in the field. You may also reference these instructions when adding other top grab handles, including the 202A Grab (GO-ES Seat only).

Note: When ordering accessories/parts, hardware to be included.

Required Tools



These instructions apply to the **GO-ES Seat** by Freedman Seating Co. [Watch the video here.](#)

1. Measure at the top of the seat back.
Holes are located at 5-3/8" and 9-3/8" from end.
Holes are 3-7/8" from center to center.
2. Use a drill to poke through the seat cover into designated holes.
3. Add accessory and use a 3/16" hex key to tighten provided screws (2-1/2" flat head cap screws). A hex ratchet is recommended.



US Armrest P/N 54130339 (Right) 54130341 (Left)

You may also reference these instructions when adding the Eleganza Arm and Messina Arm.

Note: No additional hardware is necessary to add US armrests.

Required Tools



These instructions apply to most Freedman seats. [Watch the video here.](#)

1. Measure from the bottom of the seat back. Hole is located at a height of 9-1/2".
2. Use a box cutter or scissors to cut a 1" incision.
3. Insert arm to fit designated hole. Push arm inwards and turn counterclockwise (left arm) or clockwise (right arm).

