

Technical Bulletin: 2019.02

PreFixx® Protective Finish Chemical & Disinfectant Resistance

Subject:

Guidance for Disinfection

Summary:

OMNOVA Solutions manufactures a variety of performance fabrics sold under brands such as **Boltaflex**®, **BoltaSoft**®, **Nautolex**® and **PreVaill**®. Many of the performance fabrics feature a **PreFixx**® protective finish, which resists damage from disinfectants.

Cleaning After Disinfection:

The following cleaners should be used with a soft cloth or damp sponge to remove chemical residue.

- Formula 409® All-Purpose spray cleaner
- Hand dishwashing soap and water

After cleaning, rinse area with clean water, then dry with a clean, lint-free cloth. Failure to remove chemical residue will cause discoloration of the coated fabric surface to manifest earlier in the life cycle of the product.

Disinfectant Use:

In laboratory testing, upholstery protected with **PreFixx** finish was treated with the following disinfectants with little to no discoloration or damage to the upholstery. This testing may not reflect actual results in the field.*

Please see reverse side for full list of recommended disinfectants.

Recommended Disinfectants**

- Agar™ Powerquat
- Asepticare™
- Asepticare™ TB-II
- AVISTAT-D™ Ready To Use Spray Disinfectant Cleaner
- Biotrol BirexSE®
- Bleach 1:5 (20% bleach)
- Bleach 1:9 (10% bleach)
- Bleach-Rite® Disinfecting Spray
- CaviCide™
- CaviCide1™
- CaviCide™ AF
- Clorox® Broad Spectrum Quaternary Disinfectant Cleaner
- Clorox® Healthcare Bleach Germicidal Cleaner
- Clorox® Healthcare Bleach Germicidal Wipes
- Clorox® Healthcare EZ-KILL® Wipes
- Clorox® Healthcare VersaSure® Cleaner Disinfection Wipes
- Clorox® Hydrogen Peroxide Cleaner Disinfectant Spray
- Clorox® Hydrogen Peroxide Cleaner Disinfectant Wipes
- Diversey™ Accel® INTERvention® Wipes
- Diversey™ Avert® Sporidical Disinfectant Cleaner
- ERC Performance Wipes
- McKesson Disposable Germicidal Surface Wipes
- McKesson Pro-Tech RTU Disinfectant Cleaner
- OPTIM® 1 Wipes
- OPTIM® 33TB
- Oxivir® 1 RTU
- Oxivir® Five 16
- Oxivir® TB
- OxyCide™ Daily Disinfectant Cleaner
- PDI Sani-Cloth® AF3 Germicidal Disposable Wipes
- PDI Sani-Cloth® HB
- PDI Sani-Cloth® Plus
- PDI Sani-Cloth® Prime Germicidal Disposable Wipe
- PDI Super Sani-Cloth®
- PDI Super Sani-Cloth® Bleach Germicidal Disposable Wipes
- Precise QTB Spray
- PROCHEM® Oxy Plus
- Purell® Healthcare Surface Disinfectant
- Purell® Multi-Surface Disinfectant
- Sani Professional® Cleaning + Degreasing Multi-Surface Wipes
- Sani Professional® Multi-Surface Cleaning Wipes
- Sani Professional® No-Rinse Sanitizing Multi-Surface Wipes
- SaniZide® Plus
- STERI-7 XTRA CONCENTRATE (recommended dilution ratio 1:10)
- STERI-7 XTRA WIPES
- Vert-2-Go ED
- Virox AHP 5
- Virox PREempt™ RTU
- Virex® II 256
- Virex® Plus One-Step Disinfectant Cleaner & Deodorant
- Wayne® Concept 256N
- Wex-Cide 128

* All disinfectants and cleaning agents contain chemicals that degrade coated fabric upholstery to some extent. To promote a long product life, it is recommended that the PreFixx cleaning and maintenance protocol be employed regularly.

**Inclusion in this document does not imply "fit for use." Customers should first determine if products are appropriate for use on their surfaces.

Revision Date: 03-Apr-20

Page 2 of 2

www.omnova.com



North American Headquarters
25435 Harvard Road
Beachwood, OH 44122
United States
PHONE +1 800 457-9900